Description	ted only by a fully qualified instal Illustration	Qty
Radiator		1
Bracket		4
Connection part		4
Fixing screw		4
Wall Anchor		4
Security Screw		4

	1
Description	Illustration
Fixings choose the appropriate fixing for the wall material if required	The and an and and
PTFE tape	PTFE
Electric drill	
Masonry drill bit appropriate to the fixings	
Adjustable spanner	
Radiator valve Hex Key	
Flat head and Philips head screw drivers	
1 Lock shield valve and 1 Gate or Thermostatic valve	
Spirit level	
Measuring tape	<u>Contractions and and and and and and and and and and</u>

V	

GENERAL RECOMMENDATION

Before fitting the radiator it is necessary to wash out the heating system to remove any existing mud, scale, work residues, iraces of flux, oil, etc... When the system water pH is outside the 5,5 - 6,5 range and / or when the dissolved is abrove 0,1mg/L., it is always needed to protect the heating system components (The radiator is one of these) with a proper chemical treatment compatible with all parts in contact with water (Siilicon rubber too). In order to fit the radiator to the wall, it is necessary to choose the proper fixings for the wall material. If the system water exceeds 50 centigrad degree, please install a warming mark near the radiator to avoid any accidental scalding. Clean the radiator surface only with a soft cloth to avoid scratching the finish and do not use chemical against during cleaning operations. It is prohibited to climb on the radiator. Maximum working temperature: 95 centigrad degree, maximum working pressure 4 bar.

